

Having trouble?



Don't worry

The Boat Won't Start

We get this call a lot. Almost always the boat is not in neutral. Wiggle the shifter until it is directly in the center (between all the way forward and all the way backward). If the boat is not in neutral, you will hear a “beep” when you turn the key to start the engine.

The Boat is Running, but Beeping a Lot

If this happens, please call the office ASAP. The beeping could indicate an engine issue. Running the motor could cause serious damage.

The Anchor Won't Hold

The anchors we use are designed for a muddy, sandy bottom. If winds are under 20mph, the anchors should hold your boat in place with very little slippage. The solution to this problem is to LET MORE LINE OUT. You can try “re-tossing” the anchor, but letting more anchor rope out is usually the answer.

All Other Issues

Please call the office (641) 357-3535